

mediumVOLTAGE

ORMAZABAL
velatia



ekorsys units:

automation, control, protection, metering and communications
of the electrical network

ekor.rpa

Multifunctional protection unit

mediumVOLTAGE AG
Langackerstrasse 25
CH 6330 Cham
Tel. +41 41 783 18 18
Fax +41 41 783 18 19
info@mediumvoltage.ch
www.mediumvoltage.ch

Reliable innovation. Personal solutions.

www.ormazabal.com

Technical characteristics

ekor.rpa		ekor.rpa-110	ekor.rpa-120
General characteristics			
24/48/125 V _{dc}		●	●
Current analog inputs		4 + I _o ⁽¹⁾	4 + I _o ⁽¹⁾
Voltage analog inputs ⁽²⁾			3 + V _o ⁽¹⁾
Configurable digital inputs/outputs		9/4	9/4
Setting groups		1	1
Protection functions			
50-51[1]-51[2]	50N-51N[1]-51N[2]	50Ns-51Ns	●
46	46BC		●
67	67N ⁽³⁾	67Ns ⁽³⁾	●
49			●
27	59	59N	●
Measurements			
Current		●	●
Voltage	Active/Reactive/Apparent power		●
Energy P+, P-, Q1,...,Q4	Phi angle (φ)		●
Control and supervision			
Circuit Breaker control & operation	Lock-out (86)	●	●
Trip coil supervision (TCS)	Voltage presence/absence	●	●
Events record		4000	4000
Fault record		10	10
LEDs/Configurable LEDs		4/0	4/0
Trip blocked by 2 nd harmonic		●	●
Recloser (79)		●	●
Configuration through software		●	●
Configuration through web		●	●
Front communication ports		● miniusb	● miniusb
Rear communication ports		● RS-485	● RS-485
Communications: Serial⁽⁴⁾			
MODBUS-RTU	PROCOME	●	●
Communications: IP⁽⁵⁾			
MODBUS-TCP	DNP3 TCP	○	○
IEC 60870-5-104	IEC 61850	○	○

Notes:

⁽¹⁾ Calculated

⁽²⁾ Voltage sensing capabilities according to model features

⁽³⁾ Angular and Wattmetric

⁽⁴⁾ Check with **Ormazabal** other protocols

⁽⁵⁾ Check with **Ormazabal** your IP protocol needs

Configuration:

● Standard

○ Optional



ANSI functions

- 27 - Undervoltage relay
- 46 - Negative sequence / unbalance relay
- 46BC - Broken conductor detection
- 49 - Machine or transformer thermal relay
- 50 - Instantaneous overcurrent relay
- 50N - Instantaneous earth overcurrent relay
- 50NS - Instantaneous sensitive earth overcurrent relay
- 51 - Inverse time overcurrent relay
- 51N - Inverse time earth overcurrent relay
- 51NS - Inverse time sensitive earth overcurrent relay
- 59 - Overvoltage relay
- 59N - Residual overvoltage relay
- 67 - Directional overcurrent relay
- 67N - Directional earth fault relay
- 67NS - Directional sensitive earth fault relay
- 79 - Reclosing relay (auto reclosing)
- 86 - Lockout relay

mediumVOLTAGE_{AG}
Langackerstrasse 25
CH 6330 Cham
Tel. +41 41 783 18 18
Fax +41 41 783 18 19
info@mediumvoltage.ch
www.mediumvoltage.ch



mediumVOLTAGE